



MANDO A DISTANCIA PARA DETECTOR DE MOVIMIENTO CAMPANA UFO INTELIGENTE OSRAM

55,73€ IVA incluido

Mando a distancia para la Campana LED UFO inteligente. Con él **podrás controlar tanto el encendido como el apagado, así como el consumo, el brillo, la sensibilidad del sensor, el tiempo de espera, etc.**

SKU: MANDOUFO

Category: [Focos LED industriales](#)

Tag: [Campanas LED UFO](#)

DATOS TÉCNICOS

Peso	0.050000
Material	Termoplastico
Tamaño	12,5 x 7,5 x 2 cm
Garantía	5 años

GALERÍA DE IMÁGENES



KEY DESCRIPTIONS

KEY	FUNCTION	KEY	FUNCTION
OFF	Press the on/off button, the light goes to permanent on or permanent off mode. If the sensor is locked, MUST Press/AUTO* to quit from this mode.	LOCK	Press "Auto/lock" the sensor starts to work automatically and all parameters remain the same as the latest stable in each mode.
ON/OFF	Display current parameters	TEST	The button "TEST" is for testing purpose, usually used to check the sensor automatically after commissioning. Meanwhile the stand-by period and daylight sensor are disabled. Press/AUTO* to quit from this mode.
MEMO	Upload the selected parameters to sensors	MEMO	When the light level exceeds the setting, the light will turn off again when the sensor is locked. The stand-by period parameter will remain in order to return to the light level parameter in the subsequent mode. Switch the mode to the previous mode by pressing the arrow keys. The light will turn on again when the stand-by period is reached. Press "MEMO" to save the setting, and press "OFF" to close the light sensor adjustment.
MEMO	Enter in the setting condition and navigate to UP and Down	MEMO	Four modes with existing parameters which are available to be updated and saved in Mode.
MEMO	Navigate to Right and Left	MEMO	Select (MEMO) will be used to save (MEMO) parameter or delete it. Press (MEMO) to save or delete the parameter. Press (MEMO) to return to the light level parameter in the next mode. Press (MEMO) to return to the light level parameter in the next mode.
MEMO	Confirm selected parameters and saving	MEMO	Select (MEMO) will be used to save (MEMO) parameter or delete it. Press (MEMO) to save or delete the parameter. Press (MEMO) to return to the light level parameter in the next mode.
MEMO	Default settings.	MEMO	Select (MEMO) will be used to save (MEMO) parameter or delete it. Press (MEMO) to save or delete the parameter. Press (MEMO) to return to the light level parameter in the next mode.
BRIGHTNESS	Adjust the light brightness during hold time	MEMO	Select (MEMO) will be used to save (MEMO) parameter or delete it. Press (MEMO) to save or delete the parameter. Press (MEMO) to return to the light level parameter in the next mode.
SENSITIVITY	Adjust sensor sensitivity	MEMO	Select (MEMO) will be used to save (MEMO) parameter or delete it. Press (MEMO) to save or delete the parameter. Press (MEMO) to return to the light level parameter in the next mode.
HOLD TIME	The time of light flicker remains at programmed 90%/60%/30% level after motion is not detected	MEMO	Select (MEMO) will be used to save (MEMO) parameter or delete it. Press (MEMO) to save or delete the parameter. Press (MEMO) to return to the light level parameter in the next mode.
STANDBY TIME	Standby stand-by period at 1min/30min (Optional). Press the stand-by parameter control, future sensor switches off	MEMO	Select (MEMO) will be used to save (MEMO) parameter or delete it. Press (MEMO) to save or delete the parameter. Press (MEMO) to return to the light level parameter in the next mode.

NOTE:
The "RC100" is a universal remote programmer with ALL available settings and parameters for remote sensors. Some settings and parameters may not be available on specific type of sensor under option control mode. Please refer to the installation instruction of the sensor for the available settings and control options.

COMMAND BUTTONS

THE COMMAND BUTTONS provides a quick selection of the following operations by pressing respective buttons.

- * To turn on/off light manually press "ON/OFF" button, the sensor will lock. MUST Press/AUTO* to quit from this mode.
- * To lock manually only. Press "TEST" button, the sensor goes to test mode. Hold time is only 20s automatically after commissioning, meanwhile the stand-by period and daylight sensor are disabled. Press "AUTO" to quit from this mode.

RC-100 Sensor Remote Programmer OPERATION INSTRUCTIONS



with carrying case

SPECIFICATIONS	
Power supply	2 x AAA 1.5V battery, Alkaline preferred
Carrying case	RC-100 in carrying case
Communication	940 nm Infrared Tx & Rx
Upload range	Up to 15 m (50 ft.)
Op. temperature	0°C - 50°C (32°F - 122°F)
Dimensions	120 x 70 x 20.3 mm (4.94" x 2.76" x 0.8")

WARNING
Remove the batteries from compartment if the remote will not be used in 30 days.

OVERVIEW
The "RC100" Wireless IR Configuration Tool is a handheld tool for remote configuration of IR enabled fixture integrated sensors. The tool enables device to modify via pushbutton without ladders or tools, and stores up to four sensor parameter modes to speed configuration of multiple sensors. The "RC100" uses bidirectional IR communication to send and receive sensor settings at mounting height up to 50 feet. The device can display previously established sensor parameters, copy parameters and send new parameters or store parameter profiles. For projects where identical settings may be shared across a large number of areas or spaces, the capability provides a streamlined method of configuration. Settings can be copied throughout a site, or in different sites.

Con este mando podrás controlar las siguientes funciones:

-Puedes **subir /bajar la intensidad luminosa** y con ello los vatios de consumo. (Brightness)

-Puedes **regular** la sensibilidad del **detector** de movimiento. (Sensitivity)

-La **duración del tiempo de encendido** de la luminaria cuando no te está detectando. (Daylight Sensor)

- La **duración del tiempo de espera** (Stanby)

TODAVÍA NO HAY VALORACIONES