



## MANDO A DISTANCIA PARA DETECTOR DE MOVIMIENTO CAMPANA UFO INTELIGENTE OSRAM

**55,73€ IVA incluido**

Mando a distancia para la Campana LED UFO inteligente. Con él **podrás controlar tanto el encendido como el apagado, así como el consumo, el brillo, la sensibilidad del sensor, el tiempo de espera, etc.**

---

**SKU:** MANDOUFO

**Category:** [Focos LED industriales](#)

**Tag:** [Campanas LED UFO](#)

### DATOS TÉCNICOS

<b>Peso</b>	0.050000
<b>Material</b>	Termoplastico
<b>Tamaño</b>	12,5 x 7,5 x 2 cm
<b>Garantía</b>	5 años

### GALERÍA DE IMÁGENES



KEY DESCRIPTIONS

KEY	FUNCTION	KEY	FUNCTION
[ON/OFF]	Press the on/off button, the light goes to programmed on or off. In case of lock, the sensor is locked. MUST Press/AUTO* to quit from this mode.	[REPEAT]	Press "Auto/Repeat" the sensor starts to work automatically and all parameters remain the same as the latest stable in each mode.
[SEND]	Display current parameters	[TEST]	The button "TEST" is for testing purposes, usually used to check the sensor automatically after commissioning. Must be pressed by sensor and daylight sensor are disabled. Press/AUTO* to quit from this mode.
[UP]	Upload the selected parameters to sensors	[DOWN]	When the light level exceeds the setting, the light will turn off when the sensor is enabled. The remote light level parameter for 1 sensor in order to control the light level response is set. However, when the sensor is disabled, the light will turn on, unless the remote is disabled. Press/AUTO* to quit from this mode.
[LEFT]	Enter in the setting condition and navigate to UP and Down	[RIGHT]	When the light level exceeds the setting, the light will turn off when the sensor is enabled. The remote light level parameter for 1 sensor in order to control the light level response is set. However, when the sensor is disabled, the light will turn on, unless the remote is disabled. Press/AUTO* to quit from this mode.
[LEFT]	Navigate to Right and Left	[RIGHT]	When the light level exceeds the setting, the light will turn off when the sensor is enabled. The remote light level parameter for 1 sensor in order to control the light level response is set. However, when the sensor is disabled, the light will turn on, unless the remote is disabled. Press/AUTO* to quit from this mode.
[OK]	Confirm selected parameters and saving	[MODE]	Four modes with existing parameters which are available to be updated and saved in Mode.
[ENTER]	Default settings.	[MODE]	Four modes with existing parameters which are available to be updated and saved in Mode.
[BRIGHTNESS]	Adjust the light brightness during hold time	[MODE]	Four modes with existing parameters which are available to be updated and saved in Mode.
[SENSITIVITY]	Adjust sensor sensitivity	[MODE]	Four modes with existing parameters which are available to be updated and saved in Mode.
[HOLD TIME]	The time of light fixture remains at programmed 90%/50%/10% level after motion is not detected	[MODE]	Four modes with existing parameters which are available to be updated and saved in Mode.
[STANDBY TIME]	Standby stand-by period at 1min/30min (Optional). Press the stand-by period control, future sensor switches off.	[MODE]	Four modes with existing parameters which are available to be updated and saved in Mode.

NOTE:  
The "RC100" is a universal remote programmer with ALL available settings and parameters for remote sensors. Some settings and parameters may not be available on specific type of sensor under option control mode. Please refer to the installation instruction of the sensor for the available settings and control options.

COMMAND BUTTONS

THE COMMAND BUTTONS provides a quick selection of the following operations by pressing respective buttons.

- \* To turn on/off light manually press "ON/OFF" button, the sensor is locked. MUST Press/AUTO\* to quit from this mode.
- \* To test manually only. Press "TEST" button, the sensor goes to test mode. Hold time is only 20s automatically after commissioning, meanwhile the stand-by period and daylight sensor are disabled. Press "AUTO" to quit from this mode.

**RC-100**  
Sensor Remote Programmer  
**OPERATION INSTRUCTIONS**

with carrying case

**SPECIFICATIONS**

Power supply	2 x AAA 1.5V battery, Alkaline preferred
Carrying case	RC-100 in carrying case
Communication	940 nm Infrared Tx & Rx
Upload range	Up to 15 m (50 ft.)
Op. temperature	0°C - 50°C (32°F - 122°F)
Dimensions	125 x 70 x 20.3 mm (4.9" x 2.76" x 0.8")

**WARNING**  
Remove the batteries from compartment if the remote will not be used in 30 days.

**OVERVIEW**  
The "RC100" Wireless IR Configuration Tool is a handheld tool for remote configuration of IR enabled fixture integrated sensors. The tool enables device to modify via pushbutton without ladders or tools, and stores up to four sensor parameter modes to speed configuration of multiple sensors. The "RC100" uses bidirectional IR communication to send and receive sensor settings at mounting height up to 50 feet. The device can display previously established sensor parameters, copy parameters and send new parameters or store parameter profiles. For projects where identical settings may be shared across a large number of areas or spaces, the capability provides a streamlined method of configuration. Settings can be copied throughout a site, or in different sites.

Con este mando podrás controlar las siguientes funciones:

- Puedes **subir /bajar la intensidad luminosa** y con ello los vatios de consumo. (Brightness)
- Puedes **regular** la sensibilidad del **detector** de movimiento. (Sensitivity)
- La **duración del tiempo de encendido** de la luminaria cuando no te está detectando. (Daylight Sensor)
- La **duración del tiempo de espera** (Stanby)

**TODAVÍA NO HAY VALORACIONES**